INSTRUCTIONS

Sconce 3 rotating straight arms

1. Unpack without using any cutter or scissor because of possible scratches. Release the packaging of reflectors without removing it completely.



- 2. Unscrew carefully the 4 screws to remove the back of the rectangular housing.
- 3. Fix the rectangular plate to the wall, respecting the verticality of the lamp.
- **4.** Fix the lower curved tube into the central tube. Screw the hexagonal brass screw without tighten it otherwise painting could be damaged.
- **5.** Fix the upper big curved tubes into the central tubes. Fix the upper straight tubes into the big curved tubes then screw the hexagonal brass screws at the fitting.
- **6.** At this stage, at least 2 operators are necessary. One maintains the lamp, second operator connects electrical wires, then fit the rectangular housing into the rectangular plate on the wall . Then screw the 4 screws.
- 7. Remove completely the packaging.
- **8.** Before moving the arms, the screw must not be tightened otherwise painting could be damaged.





