


Design House *Stockholm*




Assembly Instructions
Kalo Lamp (2749—0100)
& (2749—1000)


WARNING If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

CARE To avoid leaving marks on the glass, we recommend to use gloves or handle the glass without touching the inner sandblasted surface. We recommend the glass is cleaned with a clean cloth and non-abrasive cleaner, such as clean soapy water or a proprietary window cleaner. For glass with sandblasted surface, a stiff bristle or nylon brush can be used to remove dirt from the recesses in the surface. The glass is dishwasher safe.


Components:




1




2




3




4




5




6





7



8



7



8